



Getriebe - Innenteile

Bild-Nr.	Stck.	Teilbezeichnung	Teile-Nr.	Best.- u. Lager-Nr.
1	1	Kugelkopf KK 32-10	17142-01-9	10-524
2	1	Hebel, vollst.	96-00020-3	26-091
3	1	Welle	90-00066-2	28-043
4	1	Spiralstift S 4x20	13053-02-0	10-260
5	1	O-Ring 10x2	15286-07-2	05-771
	1	Sicherungsring 12x1 DIN 471	12610-03-6	07-244
6	1	Hebel	90-00067-0	28-042
7	1	Zyl.-Stift 10x24 DIN 6325	13033-03-0	04-573
8	1	Sicherungsring 17x1 DIN 471	12610-08-5	02-223
9	4	Paßscheibe 17x24x1 DIN 988	12335-06-3	15-518
10	2	Nadelkäfig K 17x13	14673-01-6	15-517
11	1	Buchse	90-00016-7	15-516
12	1	Achse	90-00017-5	15-515
13	1	Doppelrad	90-05082-4	39-082
14	4	Paßscheibe 17x24x1 DIN 988	12335-06-3	15-518
15	1	Sicherungsring 17x1 DIN 471	12610-08-5	02-223
16	5	Kugellager 6205 DIN 625	14110-07-6	05-228
17	1	Zahnrad	90-00032-4	28-039
18	1	Zapfwelle	90-00033-2	28-041
19	1	Kugellager 6304 DIN 625	14110-40-7	05-238
20	1	Paßscheibe 20x28x1,2 DIN 988	12335-24-6	04-763
21	2	Kugellager 1604 DIN 625	14110-04-3	05-205
22	1	Sicherungsring 42x1,75 DIN 472	12660-05-6	15-444
23	1	Zahnrad	90-02714-5	28-084
24	1	Schaltrad	90-05080-8	39-084
25	2	Sicherungsring 25x1,2 DIN 471	12610-10-1	02-246
26	1	Welle	90-05084-0	39-080
27	2	Nadelkäfig K 12x17x13	14673-02-4	15-514
28	1	Zwischenrad	90-05087-3	39-079
29	1	Paßscheibe 42x52x1,6 D.988	12335-25-3	04-767
	2	Paßscheibe 42x52x0,5 D. 988	12335-26-1	04-764
30	3	Kugellager 6006 DIN 625	14110-05-0	05-216
31	1	Welle	90-00019-1	28-028
32	3	Sicherungsring 30x1,5 DIN 471	12610-12-7	05-440
33	1	Zahnrad	90-05081-6	39-083
34	1	Zahnrad	90-05083-2	39-081
35	1	Schaltrad	90-05085-7	39-077
36	1	Stützscheibe SS 30x42x2,5	12334-03-3	15-512
37	1	Zahnrad, vollst.	96-00874-3	39-103
38	1	Welle	90-00020-9	28-033
39	1	O-Ring 20x2	15286-10-7	15-509
40	1	Bremsklotz	90-00044-9	26-099
41	1	Scheibe	90-00021-7	15-513